



DJI PHANTOM 3 PROFESSIONAL CHECKLIST

1. DJI PHANTOM 3 PRO AIRCRAFT PRE-FLIGHT CHECKLIST

- Gimbal Clamp (Removed; Stowed)
- Micro SD Card (Installed; Available Space)
- Format SD Card (As Necessary)
- Battery (Installed; Status Check Fully Charged)
- Propeller (Check Condition; Installed Black On Black, White On White)
- CHECK COMPLETE

2. DJI PHANTOM 3 PRO CONTROLLER PRE-FLIGHT CHECKLIST

- Tablet, Phone (Mounted, Plugged In)
- Sun Shield If Applicable (Mounted, Adjusted)
- Antennas (Positioned)
- Flight Mode Switch (Desired Position)
- Battery (Status Check Fully Charged)
- CHECK COMPLETE

3. DJI PHANTOM 3 PRO CONTROLLER BEFORE ENGINE START CHECKLIST

- Power On (Controller)
- Battery Status (Double Checked)
- Controller LED (Green)
- Controller Status LED (Checked, No Errors)
- Power On (Tablet, Phone)
- Unnecessary Apps & Features (Exit, Turn Off)
- DJI Pilot App (Launch)
- Camera Icon (Select)
- Camera Options (Checked, Set)
- Compass Calibration (If Different Launch Site)
- CHECK COMPLETE

4. DJI PHANTOM 3 PRO AIRCRAFT BEFORE ENGINE START CHECKLIST

- Aircraft (On A Level Surface)
- Propellers (Double Check Tightness)
- Power On (Aircraft)
- Battery (Status Check Fully Charged, No Errors)
- Compass Calibration (If Different Launch Site)
 - Interference (Check No Large Metal Surfaces, Cars, Concrete)
 - Ferromagnetic Materials (Check No Keys Or Cell Phone On Person Or Near Aircraft)
- Proceed With Calibration
- Aircraft Status LED's (Checked, No Errors)
- Aircraft (On A Level Surface)
- Aircraft Orientation (Nose Away From Operator)
- CHECK COMPLETE

5. DJI PHANTOM 3 PRO TAKEOFF CHECKLIST

- DJI Pilot App Flight Status (Check Safe To Fly – GPS, Safe To Fly - VPS)
- Launch Site (Clear, Safe For Take Off)
- Start Motors (Both Control Sticks To Lower - Inner Position)
- Take Off (Auto, Manual)
- Low Hover (Check Hover Stability)
- Flight Controls (Move Each Stick Check Proper Stability & Control)
- CHECK COMPLETE
- FLY SAFE!!!